





## Contents

<b>1. General Description .....</b>	<b>7</b>
1.1 Coding Principle .....	8
1.2 Feature.....	8
1.3 Technical Specifications.....	10
1.3.1 Specification .....	10
1.3.2 Pump Performance.....	10
1.3.3 Reference Formula of Mould Controllers Model Selection.....	11
1.4 Safety Regulations.....	12
1.4.1 Safety Signs and Labels .....	12
1.4.2 Signs and Labels .....	13
1.4.3 Operation Regulations .....	14
1.5 Exemption Clause .....	16
<b>2. Structure Characteristics and Working Principle .....</b>	<b>17</b>
2.1 Working Principle .....	17
2.2 Assembly Drawing .....	18
2.2.1 Assembly Drawing (STM-4575F).....	18
2.2.2 Parts List (STM-4575F) .....	19
2.2.3 Heat Exchanger Drawing.....	20
2.2.4 Water Inlet Contector Assembly .....	21
2.2.5 Oil pipe from pump Assembly.....	22
2.2.6 Heating Hopper Assembly .....	23
2.2.7 Oil Tank Assembly.....	25
2.2.8 Oil Discharge Connector Assembly .....	26
2.2.9 Water Drainage Connector .....	27
2.3 Electrical Diagram .....	28
2.3.1 Main Circuit (STM-4575F) (400V).....	28
2.3.2 Control Circuit (STM-4575F) (400V).....	29
2.3.3 Electrical Components Layout (STM-4575F) (400V) .....	30
2.3.4 Electrical Components List (STM-4575F) (400V) .....	31
2.3.5 Main Circuit (STM-4575F) (230V).....	32
2.3.6 Control Circuit (STM-4575F) (230V).....	33

2.3.7	Electrical Components Layout (STM-4575F) (230V) .....	34
2.3.8	Electrical Components List (STM-4575F) (230V) .....	35
2.4	Main Electrical Components Description.....	36
2.4.1	Overload Relay .....	36
<b>3.</b>	<b>Installation and Debugging.....</b>	<b>37</b>
3.1	Installation Space .....	37
3.2	Pipeline Connection .....	38
3.3	Power Connection.....	39
<b>4.</b>	<b>Operation Guide .....</b>	<b>40</b>
4.1	Control Panel .....	40
4.2	Structure of the Unit .....	43
4.3	Machine Startup .....	44
4.4	Stop the Machine .....	52
<b>5.</b>	<b>Trouble-shooting .....</b>	<b>53</b>
<b>6.</b>	<b>Maintenance and Repair .....</b>	<b>55</b>
6.1	Y Type Strainer Cleaning .....	56
6.2	Solenoid Valve .....	56
6.3	Heater Pipe Cleaning .....	57
6.4	Printed Circuit Board .....	58
6.5	Display Terminal Connecting Diagram.....	60
6.6	Maintenance Schedule.....	61
6.6.1	About the Machine.....	61
6.6.2	Installation & Inspection.....	61
6.6.3	Daily Checking.....	61
6.6.4	Weekly Checking .....	61
6.6.5	Trimonthly Checking.....	61
6.6.6	Half-yearly Checking.....	61
6.6.7	Yearly Checking.....	62
6.6.8	3 year Checking.....	62

## Table Index

Table 1-1: Specification.....	10
-------------------------------	----

Table 1-2: Standard Water Quality .....	15
Table 2-1: Parts List (STM-4575F).....	19
Table 2-3: Heat Exchanger Parts List .....	20
Table 2-4: Water Inlet Contector Parts List.....	21
Table 2-5: Oil pipe from pump parts list.....	22
Table 2-6: Heating Hopper Parts List.....	24
Table 2-7: Oil tank Parts List .....	25
Table 2-8: Oil Discharge Connector Parts List.....	26
Table 2-9: Water Drainage Connector Parts List .....	27
Table 2-10: Parts List (STM-4575F) (400V).....	31
Table 2-11: Parts List (STM-4575F) (230V).....	35
Table 4-1: Control Panel.....	40
Table:4-2: Error Type.....	42

### Picture Index

Picture 1-1: Pump Performance.....	10
Picture 2-1: Working Principle.....	17
Picture 2-2: Assembly Drawing (STM-4575F).....	18
Picture 2-3: Heat Exchanger Drawing .....	20
Picture 2-4: Water Inlet Contector Assembly .....	21
Picture 2-5: Oil pipe from pump Assembly .....	22
Picture 2-6: Heating Hopper Assembly .....	23
Picture 2-7: Oil tank drawing .....	25
Picture 2-8: Oil Discharge Connector Assembly .....	26
Picture 2-9: Water drainage connector drawing .....	27
Picture 2-10: Main Circuit.....	28
Picture 2-11: Control Circuit (STM-4575F) (400V) .....	29
Picture 2-12: Electrical Components Layout (STM-4575F) (400V) .....	30
Picture 2-13: Main Circuit ( STM-4575F)(230V).....	32
Picture 2-14: Control Circuit (STM-4575F)(230V) .....	33
Picture 2-15: Electrical Components Layout (STM-4575) (230V) .....	34
Picture 2-16: Overload Relay .....	36
Picture 3-1: Installation Space .....	37

Picture 3-2: Ball Valve.....	38
Picture 3-3: Pipeline Connection.....	38
Picture 4-1: Control Panel.....	40
Picture 4-2: Menu Outline.....	43
Picture 4-3: Main Power Switch.....	44
Picture 4-4: Initial Menu.....	44
Picture 4-5: Control Setting.....	45
Picture 4-6: Alarm Setting.....	46
Picture 4-7: Output Setting.....	47
Picture 4-8: Temperature Setting.....	48
Picture 4-9: Time Setting.....	49
Picture 4-10: Communication Setting.....	50
Picture 4-11: Equipment Setting.....	51
Picture 4-12: Operation Screen.....	52
Picture 6-1: Y Type Strainer.....	56
Picture 6-2: Solenoid Valve.....	56
Picture 6-3: Heater Pipe 1.....	57
Picture 6-4: Heater Pipe 2.....	57

# 1. General Description




Read this manual carefully before operation to prevent damage of the machine or personal injuries.

STM-F series "Large Flow" oil heater mainly applied in extruder and rubber injection molding or other occasion requires large flow, strong cooling capability. Besides, it's also applicable to the fields with same requirements. This series of heaters adopt indirect cooling method after return oil from the mould passed through the cooler. The oil pressurized by pump, through heater pipe it will be heated, then it returns to the mould to reach the requirement of heating and maintaining constant temperature. Adopts P.I.D temperature controller can ensure stable temperature control.



Model: STM-4575F

## 1.1 Coding Principle



## 1.2 Feature

### Standard Configuration

- 1) It's easy for dismantlement and maintenance.
- 2) P.I.D. full-digital temperature control system can reach maximum temperature at 200°C and maintain a mould temperature with accuracy of  $\pm 0.5^{\circ}\text{C}$  at any status.
- 3) Controller adopts 3.2" LCD for easy operation.
- 4) It equipped with large-flow pump which especially suitable for moulds requiring large-flow heating medium to maintain constant temperature in plastics molding occasions.
- 5) Cooler adopted plate heat exchanger has optimal exchanging effect which can reach the highest cooling ability to 40kW and lower temperature quickly.
- 6) Power phase reverse alarm, pump overload alarm, over-temperature alarm, low level sensor alarm and other safety devices can self-detect machine's abnormality and display the abnormal situations.

### Accessory option

- 1) Water manifolds, Teflon hose and Transfer oil are optional.
- 2) RS485 communication function is optional.
- 3) Display of mould temperature and mould return oil temperature is optional.
- 4) When machine stops, return oil reverse function is optional.



All service work should be carried out by a person with technical training or corresponding professional experience. The manual contains instructions for both handling and servicing. Chapter 6, which contains service instructions intended for service engineers. Other chapters contain instructions for the daily operator.

Any modifications of the machine must be approved by SHINI in order to avoid personal injury and damage to machine. We shall not be liable for any damage caused by unauthorized change of the machine.

Our company provides excellent after-sales service. Should you have any problem during using the machine, please contact the company or the local vendor.

Headquarter and Taipei factory:  
Tel: (886) 2 2680 9119

China Service Line:  
Tel: 800 999 3222

## 1.3 Technical Specifications

### 1.3.1 Specification

Table 1-1: Specification

Model	Heater Power (kW)	Pump power (HP)	Max. pump Flow (L / min)	Max. pump pressure (bar)	Heating Tank Number	Main / Sub. Oil Tank (L)	Cooling Method	Mould Coupling* (inch)	Inlet/Outlet (inch)	Cooling Water Inlet/Outlet (inch)	Dimensions (mm) (H×W×D)	Weight (kg)
STM-4575F	45	7.5	424	3.0	3	16 / 51	Indirect	1 7/8" -12(1x2)	1.5" / 1.5"	13 / 13	1200x500x1350	270


Note:: 1) "\*" Stands for options.

2) Pump testing standard: Power of 50 Hz, purified water at 20°C. (There is ±10% tolerance for either max. flowrate or max. pressure).

3) Power supply: 3Φ, 400VAC, 50 Hz

We reserve the right to change specifications without prior notice

### 1.3.2 Pump Performance



Picture 1-1: Pump Performance

### 1.3.3 Reference Formula of Mould Controllers Model Selection

Heater Power (kW) = mould weight (kg) × mould specific heat (kcal/kg°C) × temperature difference between mould and environment (°C) × safety coefficient / heating duration / 860

Note: safety coefficient can select a value from 1.3 to 1.5.

Flow Rate (L/min) = heater power (kw) × 860 / [heating medium specific (kcal/kg°C) × heating medium density (kg/L) × in/outlet temperature difference (°C) × time (60)]

Note: Water specific heat =1kcal/kg°C

Heating medium oil specific heat =0.49kcal/kg°C

Water density =1kg/L

Heating medium oil density =0.842kg/L

## 1.4 Safety Regulations

Strictly abide by the following safety regulations to prevent damage of the machine or personal injuries.

### 1.4.1 Safety Signs and Labels



#### Danger!

The unit is designed to endure high temp, and high pressure. For safe operation, do not remove the covers or switches.



#### Attention!

The unit should be operated by qualified personnel only.

During operation, avoid wearing gloves or clothes that may cause danger.

Turn off main switch when power supply is off.

Stop the unit when there may be power supply problems caused by static electricity.

Put on safety gloves and shoes during installation or relocation.

Components from our company can only be used for replacement.



#### Warning!

Do not touch the switch with wet object or hands.

Do not use the machine before fully aware of its performance.

Be careful not to touch or hit the switch or sensor.

Please put spare emergency switch in suitable place and remember the location.

Please keep enough operation space, and keep away obstacles.

To avoid producing statics, clean the floor from oil or water to keep a dry environment.

Protect the machine against severe vibration or collision.


Don't take off or dirty safety signs privately. Drunken, medicine-taking, or men without proper judgement should not operate the machine.






#### Warning!

All screws of electric components in cabinet have been tightened and no need for periodical checking.

### 1.4.2 Signs and Labels

 <table border="1"> <thead> <tr> <th>項目Item</th> <th>週期CT</th> </tr> </thead> <tbody> <tr> <td>檢查管路接頭是否鬆動 Check whether pipeline joints are under looseness.</td> <td>每周 Weekly</td> </tr> <tr> <td>清洗Y型過濾器 Clean Y-type filter.</td> <td>每周 Weekly</td> </tr> <tr> <td>清洗電磁閥 Clean solenoid valve.</td> <td>每月 Monthly</td> </tr> <tr> <td>檢查EGO靈敏性 Check the sensitivity of EGO.</td> <td>每周 Weekly</td> </tr> <tr> <td>檢查液位開關 Check level switch.</td> <td>三個月 Trimonthly</td> </tr> <tr> <td>檢查接觸器 Check contactor.</td> <td>三個月 Trimonthly</td> </tr> <tr> <td>清洗電熱管/冷卻器 Clean process heater/cooler.</td> <td>六個月 Semiyearly</td> </tr> <tr> <td>檢查指示燈、蜂鳴器動作是否正常 Check indicator and buzzer.</td> <td>六個月 Semiyearly</td> </tr> <tr> <td>PCB板 PCB renewal.</td> <td>3年換新 Every 3 year exchange</td> </tr> <tr> <td>無熔絲開關 No fuse breaker.</td> <td>3年換新 Every 3 year exchange</td> </tr> <tr> <td rowspan="3">熱煤油 Thermal oils</td> <td>≤120℃ Renew annually</td> </tr> <tr> <td>120℃~160℃ Renew semiyearly</td> </tr> <tr> <td>&gt;160℃ Renew trimonthly</td> </tr> </tbody> </table> <p>注：詳細操作方法，請參考產品說明書。 Note: Please refer to the Manual for detailed operations. YPS1115809000</p>	項目Item	週期CT	檢查管路接頭是否鬆動 Check whether pipeline joints are under looseness.	每周 Weekly	清洗Y型過濾器 Clean Y-type filter.	每周 Weekly	清洗電磁閥 Clean solenoid valve.	每月 Monthly	檢查EGO靈敏性 Check the sensitivity of EGO.	每周 Weekly	檢查液位開關 Check level switch.	三個月 Trimonthly	檢查接觸器 Check contactor.	三個月 Trimonthly	清洗電熱管/冷卻器 Clean process heater/cooler.	六個月 Semiyearly	檢查指示燈、蜂鳴器動作是否正常 Check indicator and buzzer.	六個月 Semiyearly	PCB板 PCB renewal.	3年換新 Every 3 year exchange	無熔絲開關 No fuse breaker.	3年換新 Every 3 year exchange	熱煤油 Thermal oils	≤120℃ Renew annually	120℃~160℃ Renew semiyearly	>160℃ Renew trimonthly	<p>Please according to schedule to make regular maintenance.</p>
項目Item	週期CT																										
檢查管路接頭是否鬆動 Check whether pipeline joints are under looseness.	每周 Weekly																										
清洗Y型過濾器 Clean Y-type filter.	每周 Weekly																										
清洗電磁閥 Clean solenoid valve.	每月 Monthly																										
檢查EGO靈敏性 Check the sensitivity of EGO.	每周 Weekly																										
檢查液位開關 Check level switch.	三個月 Trimonthly																										
檢查接觸器 Check contactor.	三個月 Trimonthly																										
清洗電熱管/冷卻器 Clean process heater/cooler.	六個月 Semiyearly																										
檢查指示燈、蜂鳴器動作是否正常 Check indicator and buzzer.	六個月 Semiyearly																										
PCB板 PCB renewal.	3年換新 Every 3 year exchange																										
無熔絲開關 No fuse breaker.	3年換新 Every 3 year exchange																										
熱煤油 Thermal oils	≤120℃ Renew annually																										
	120℃~160℃ Renew semiyearly																										
	>160℃ Renew trimonthly																										
 <p>(Attached on motor cover)</p>	<p>This is to indicate motor rotating direction. When phase reversal happens, the alarm sounds and indicator on control panel will indicate. Please exchange the place of two of the electrical wires to solve this problem.</p>																										
	<p>High voltage! Electrical shock may happen. Carefulness is required from the operator.</p>																										
	<p>Attentions! This is general warnings which operators should pay attention to.</p>																										
	<p>Oil discharge valve: oil discharge port when machine is changing oil.</p>																										
	<p>High oil level: max. oil level of machine in constant temperature.</p>																										

	<p>From mould: connector for circulating water/oil of coming from mould</p>
	<p>Pump pressure meter: indicating actual pressure of system.</p>
	<p>To mold: connector for circulating water/oil to go to mould.</p>
	<p>Oil inlet: Machine oil inlet</p>
	<ol style="list-style-type: none"> <li>1. To maintain temperature stability, cooling water pressure must be higher than 2 bar at all time, but should never exceed 5 bar in any case.</li> <li>2. Clean Y-shape Cooling Water Strainer periodically to ensure perfect cooling capacity.</li> </ol>
	<p>Water outlet: cooling water outlet</p>
	<p>Water inlet: cooling water inlet</p>

### 1.4.3 Operation Regulations

- 1) When cooling water: qualified standard cooler for industrial use is recommended. Reference as Table 1-2.
- 2) When in use, if there's poor water drainage or poor control effect, clean up the solenoid valve at once or check cooling water outlet has blockage or not.
- 3) Do not move the unit when it is in operation.
- 4) During repairing, wait until oil temperature falls below 30°C.
- 5) STM-F possesses pump overload device. When overload occurs, pump and

heater will stop working. At this moment, it needs to check overload reasons (phase shortage, pipe obstruction, broken bearing, etc.) After the system runs normally, press RESET on overload relay to rest the operation.

- 6) Before turn off the pump, wait until oil temperature falls blow 50°C. Or the service life of the unit would be affected.

Table 1-2: Standard Water Quality

No.	Control Items	Cooling Water	
		Direct Cooling Water	Circulating Cooling Water System Replenishment Water
1	pH	6.0-9.0	6.5-8.5
2	SS(mg/L) ≤	30	-
3	Turbidity ( NTU ) ≤	-	3
4	BOD5 ( mg/L ) ≤	30	10
5	CODcr ≤ ( mg/L )	-	50
6	Fe ( mg/L ) ≤	-	0.3
7	Mn ( mg/L ) ≤	-	0.1
8	Cl ( mg/L ) ≤	250	250
9	GH ( CaCO3 /mg/L ) ≤	450	450
10	Total ALK ( CaCO3 /mg/L ) ≤	500	350
11	Sulfate ( mg/L ) ≤	600	250
12	NH3-N ( mg/L ) ≤	-	10
13	Total P ( P mg/L ) ≤	-	1
14	TDS ( mg/L ) ≤	1000	1000
15	Fecal coliform ( /L ) ≤	2000	2000
16	Petroleum ( mg/L ) ≤	-	1
17	Anionic surfactant ( mg/L ) ≤	-	0.5

## 1.5 Exemption Clause


The following statements clarify the responsibilities and regulations born by any buyer or user who purchases products and accessories from Shini (including employees and agents).

Shini is exempted from liability for any costs, fees, claims and losses caused by reasons below:

1. Before use of the machine, careless or man-made installations, operation and maintenances upon machine without referring to the Manual.
2. Any incidents beyond human reasonable controls, which include man-made vicious or deliberate damages or abnormal power, and machine faults caused by irresistible natural disasters including fire, flood, storm and earthquake.
3. Any operational actions that are not authorized by Shini upon machine, including adding or replacing accessories, dismantling, delivering or repairing.
4. Use consumables or oil media that are not appointed by Shini.

## 2. Structure Characteristics and Working Principle

### 2.1 Working Principle




Picture 2-1: Working Principle

The high temperature oil returns to the machine and then be pressured by pump to the heaters. After being heated, oil will be forced to the mould and continue the circle. In the process, if the oil temperature is too high, system will activate the solenoid valve to let cooling water cool down high temperature oil indirectly until the temperature is down to the system requirement. If the temperature keeps increasing and reaches to the set point of EGO, the system will sound alarm and stop operation. The system will have low level alarm and stop working if oil level falls down below the set point.

## 2.2 Assembly Drawing

### 2.2.1 Assembly Drawing (STM-4575F)



Remarks: Please refer to material list 2.2.2 for specific explanation of the Arabic numbers in parts drawing.

Picture 2-2: Assembly Drawing (STM-4575F)

## 2.2.2 Parts List (STM-4575F)

Table 2-1: Parts List (STM-4575F)


No.	Name	Part No.
		STM-4575F
1	Movable castor 3"*	YW03000300200
2	Long door lock	YW00000000100
3	Breaker interlock*	YE41161500000
4	Big hinge-left CL203-1	YW06203100400
5	Controller MT100-01*	YE81100010000
6	Oil inlet pipe of plate heat exchanger	STM-4575F-ALL-16
7	Castor with brake 3"	YW03000300000
8	Water inlet connector assembly	STM-4575F-F-ALL
9	oil pipe from pump assembly	STM-4575F-B-ALL
10	Oil outlet pipe of plate heat exchanger	STM-4575F-ALL-15
11	Heating tank assembly	STM-4575F-A-ALL
12	H transfer to PT connector	STM-607-ALL-07/01
13	LOK-fitting 6mm*1/4"PT	YW05061400000
14	Pressure gauge (0~1.0MPa)*	YW85001000100
15	Aluminium oil cap 3/4"PT	BH12030403040
16	Oil tank assembly	STM-4575F-C-ALL
17	EGO assembly **	BH90115000050
18	Heat exchanger assembly	STM-4575F-D-ALL
19	Pump YS-35F low (YUANXIN 5.5kw) *	YM20153500000
20	Liquid level indicator assembly*	BH12060700210
21	Oil discharge connector assembly*	STM-4575F-G-ALL
22	Water drainage connector assembly*	STM-4575F-E-ALL

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

### 2.2.3 Heat Exchanger Drawing



Picture 2-3: Heat Exchanger Drawing

Table 2-3: Heat Exchanger Parts List


No.	Name	Part No.
1	Tonflon tube connector 1/2"PT×1/2"H(L)	YW04121200000
2	Plate heat exchanger (BL20-78D)	YW87957800000
3	Tonflon tube connector 3/4"PT×3/4"H	BH12030400310
4	Copper pipe coupler 3/4"PT×3/4"PT	BH12030400010
5	Solenoid valve 3/4"(KL 5231020S) *	YE32312200000

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

## 2.2.4 Water Inlet Contector Assembly



Picture 2-4: Water Inlet Contector Assembly

Table 2-4: Water Inlet Contector Parts List


No.	Name	Part No.
1	General Copper nut	BH12060703910
2	The 9th set of copper connector	-
3	Tonflon tube connector 1/4H×1/4PT	BH12010400410
4	Pipe coupler 1/2"PT×1/2"PT	BH12010230110
5	Solenoid valve 1/2" (Airtac 2L15015A)*	YE32501500000
6	Tonflon tube connector 1/2"PT×1/2"H	BH12010200210

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

## 2.2.5 Oil pipe from pump Assembly



Picture 2-5: Oil pipe from pump Assembly

Table 2-5: Oil pipe from pump parts list


No.	Name	Part No.
1	Oil pipe from pump	BH12060703910
2	LOK-fitting 12mm×1/2"PT	YW05121200000

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

## 2.2.6 Heating Hopper Assembly



Picture 2-6: Heating Hopper Assembly

Table 2-6: Heating Hopper Parts List


No.	Name	Part No.
1	Pipe coupler 1/2"PT×1/2"PT	BH12010230110
2	Stainless steel ball valve 1/2"*	YW50010200200
3	LOK-fitting connector 12mm×1/2"PT	YW05121200000
4	Heating tank insulation cotton 5	-
5	Heating tank insulation cotton 6	-
6	Heating tank insulation cotton 3	-
7	Heating tank	-
8	Heating tank insulation cotton 2	-
9	Copper pipe coupler 1/4×1/4(S-08)	BH12010400110
10	Stainless steel ball valve 1/4"PT*	YW50010400000
11	Tonflon tube connector 1/4"PT×1/4"H	BH12010400410
12	ST3.5*10 tapping screw	YW67351000000
13	Heating tank cover plate 2	-
14	Tonflon tube connector 3/4"PT×3/4"H(L)	YW04030400000
15	Heating tank insulation cotton 1	-
16	Flexible graphite washer 120×120×2.0mm**	YR20121200000
17	Pipe heater unit *	-
18	Nut M6	YW64000600300
19	Pipe heater cover	BL80091000120
20	Inner hexagon screw M10×25	YW61102500000
21	Flat washer 10	YW66102500000
22	Spring washer 10	YW65010000000
23	Heating tank insulation cotton 4	-
24	Thermocouple (2.5M)*	BE90342500050
25	Heating tank cover plate 1	-
26	LOK-fitting connector 6mm×1/4"PT L	YW05061400100

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

## 2.2.7 Oil Tank Assembly



Picture 2-7: Oil tank drawing

Table 2-7: Oil tank Parts List


No.	Name	Part No.
1	Oil tank	-
2	LOK-fitting connector 12mm×1/2"PT	YW05121200000
3	Tonflon tube connector 1/4H×1/4PT	BH12010400410
4	Tonflon tube connector 3/8H×3/8PT(L)	YW04030800300
5	Microswitch LXW5-1124 rod length 120mm*	YE14152400000
6	Nut M5	YW64000600000
7	Flat head screw M5×30	YW60530000000
8	Heat insulation pad of liquid level switch	YR10109000000
9	float ball	-
10	Flat head screw M6×15	YW63061700000

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

## 2.2.8 Oil Discharge Connector Assembly



Picture 2-8: Oil Discharge Connector Assembly

Table 2-8: Oil Discharge Connector Parts List


No.	Name	Part No.
1	3/8"PT× $\varnothing$ 13 Copper joint	-
2	General copper nut	BH12060703910
3	Water filling copper joint	-
4	1/4" Hopper bottom screw	BH12010400710
5	Tonflon tube connector 3/8"PT×3/8"H(L)	YW04030800300

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

## 2.2.9 Water Drainage Connector



Picture 2-9: Water drainage connector drawing

Table 2-9: Water Drainage Connector Parts List

No.	Name	Part No.
1	The 2 <sup>nd</sup> set of copper connector	-
2	General copper nut	BH12060703910
3	Tonflon tube connector 1/4H×1/4PT	BH12010400410
4	Tonflon tube male thread connector 1/2H×3/8PT	BH12010200310


\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.


## 2.3 Electrical Diagram

### 2.3.1 Main Circuit (STM-4575F) (400V)




Picture 2-10: Main Circuit

### 2.3.2 Control Circuit (STM-4575F) (400V)



Picture 2-11: Control Circuit (STM-4575F) (400V)

### 2.3.3 Electrical Components Layout (STM-4575F) (400V)



Picture 2-12: Electrical Components Layout (STM-4575F) (400V)

### 2.3.4 Electrical Components List (STM-4575F) (400V)

Table 2-10: Parts List (STM-4575F) (400V)


No.	Symbol	Name	Specification	Part No.
1	Q1	Breaker interlock	100A	YE41110200000
2	Q2	Breaker	25A	YE40302503000
3	Q3 Q4 Q5	Breaker	32A	YE40303203000
4	-	Excitation Tripper	-	YE40023560000
5	K1	Contactor *	220V 50/60Hz	YE00601800000
6	K2 K3 K4	Contactor **	220V 50/60Hz	YE00602822000
7	F1	Heat overload relay	9-12.5A	YE01169125000
8	F11	Fuse base	32A 2P	YE41032200000
9	-	Fuse**	2A	YE46002000100
10	F12	Breaker*	2A	YE41001000000
11	T	Transformer*	500mA	YE70402300800
12	S1	Thermocouple	K	-
13	S2 S3	Thermocouple	K	-
14	S4	Overheat protector*	-	-
15	S5	Limit switch*	250V 5(4)	-
16	PC1 A	PCB**	180~430V 50/60Hz	YE81184300200
17	X1	Terminal board	-	YE61250040000
18	-	Grounding Terminal block	-	YE61253500000
19	-	Grounding Terminal block	-	YE61063500000
20	-	Grounding Terminal block	-	YE61163500000
21	M1	Pump YS-35F*	400V 50Hz 5.5Kw	YE20153500000
22	EH1 EH2 EH3	Heater**	400V 50Hz	-
23	FM	Fan*	230V 50/60Hz	-
24	H1	Buzzer	230V 50Hz	YE84003500000
25	Y1 Y2	Solenoid valve*	230V 50/60Hz	-

\* means possible broken parts.

\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.


### 2.3.5 Main Circuit (STM-4575F) (230V)



Picture 2-13: Main Circuit ( STM-4575F)(230V)



### 2.3.7 Electrical Components Layout (STM-4575F) (230V)



Picture 2-15: Electrical Components Layout (STM-4575) (230V)

### 2.3.8 Electrical Components List (STM-4575F) (230V)

Table 2-11: Parts List (STM-4575F) (230V)

No.	Symbol	Name	Specification	Part No.
1	Q1	Breaker interlock	160A	YE41161500000
2	Q2 Q3 Q4 Q5	Breaker	50A	YE40305003000
3	-	Excitation tripper	-	YE40023560000
4	K1	Contact <sup>*</sup>	220V 50/60Hz	YE00602722000
5	K2 K3 K4	Contact <sup>**</sup>	220V 50/60Hz	YE00503600000
6	F1	Overload relay	20-25A	YE01260200000
7	F11	Fuse base <sup>*</sup>	32A 2P	YE41032200000
8	-	Fuse <sup>**</sup>	2A	YE46002000100
9	S1	Thermocouple	K	-
10	S2 S3	Thermocouple	K	-
11	S4	Overheat protector <sup>*</sup>	-	-
12	S5	Limit switch <sup>*</sup>	250V 5(4)	-
13	PC1 A	PCB <sup>**</sup>	180~430V 50/60Hz	YE81184300200
14	X1	Terminal board	-	YE61250040000
15	-	Grounding terminal block	-	YE61253500000
16	-	Grounding terminal block	-	YE61063500000
17	-	Grounding terminal block	-	YE61103500000
18	-	Grounding terminal block	-	YE61353500000
19	M1	Pump YS-35F <sup>*</sup>	230V 50Hz 5.5kW	YE20153500000
20	EH1 EH2	Heater <sup>**</sup>	230V 50Hz	-
21	FM	Fan <sup>*</sup>	230V 50/60Hz	-
22	H1	Buzzer	230V 50Hz	YE84003500000
23	Y1 Y2	Solenoid valve <sup>*</sup>	230V 50/60Hz	-

\* means possible broken parts.


\*\* means easy broken part. and spare backup is suggested.

Please confirm the version of manual before placing the purchase order to guarantee that the item number of the spare part is in accordance with the real object.

## 2.4 Main Electrical Components Description

### 2.4.1 Overload Relay

At delivery, the overload relay is set for manual reset. When motor overload occurs, stop the machine, then check and solve the problem. After that open the door of control box, press down the reset button of overload relay (if you can not press down the reset button, wait for one minute).



Picture 2-16: Overload Relay

Overload Relay Description:

- 1) Connector of connecting to contactor.
- 2) Setting current adjusting scale.  
Through largely rotating the knob, it can adjust the overload current conveniently.
- 3) Manual/ Auto reset (RESET) selects switch, reset button and tripping indication.

M: manual reset

A: automatic reset

When in manual reset, press RESET button can get equipment reset directly.

Tripping of manual reset is indicated by a projecting pin in front of it.

- 4) Test button (red).
- 5) Auxiliary contact terminals are No. 95.96.97.98. NC contacts are No. 95.96. and NO contacts are No.97.98.
- 6) Main circuit connection No. must be corresponding with terminal Number of the contactor.

### 3. Installation and Debugging

#### 3.1 Installation Space

During installation of the machine, keep at least 500mm installation space around the machine as following picture. Don't install the machine in a narrow or crowded place with other objects. This would cause inconvenience to operation, maintenance and repair.

Keep away inflammables and explosive goods.



Picture 3-1: Installation Space

## 3.2 Pipeline Connection

- 1) Open the ball valve when machine is filling the oil. After the mould is filled with oil, close the valve and start up the machine.



Picture 3-2: Ball Valve

- 2) After connect the cooling water outlet to drainage port, turn on the water source switch.



Attention!

Cooling water discharge port is shown as below. Reverse connection is forbidden.



Picture 3-3: Pipeline Connection

### 3.3 Power Connection

Make sure the power match the specification, then connect the power supply.

Please check the voltage specification signs on machine's nameplate carefully. The power supply must match the specification indicated on nameplate. The cable must match the section specification indicated in circuit diagram.

## 4. Operation Guide

### 4.1 Control Panel



Picture 4-1: Control Panel

Table 4-1: Control Panel

No.	Name	Functions	Remarks
1	LCD	Display showing LCD.	
2	POWER ON/OFF	Power ON, OFF shift key	After connect power, press "POWER ON/OFF", initial screen is displayed and starts. Pls note that electrcki shock may happen if power is on.
3	MENU	LCD menu shift key	Initial password: 0000
4	SET	Parameter setting key	Confirm paramerters
5	SV	Change set value	Modify setting temp.
6	▲/▼	Change parameters	
7	◀/▶	Cursor movement	
8	RUN/RESET	Control start and stop	


No.	Name	Functions	Remarks
9	AT	AUTO-TUNING switch start and stop	Auto-tuning can run during operation. Auto-tuning cannot work under SUCTION and COOL operation.
10	SUCTION	SUCTION relay switch start /stop key	SUCTION is to remove medium (watre/oil) from molds. Can not start during operation or cooling. After SUCTION turns on, "SUCTION relay" and "pump inverse run relay" will turn on.
11	COOL	Forced cooling switch start /stop key	Press it for 2 secs for forcedcooling, then stop heating output while output 100% cooling control. If control temp. is below Cooling Temp, forced cooling will be auto stopped then control turns off.
12	BUZZER	Turn off buzzer	Press "BUZZER" key and "BUZZER" LED lightens; buzzer and alarm relay are idle even error occurs.
13	AUTO START	Start and stop key	
14	SUCTION OFF	SUCTION relay switch start /stop key	Under SUCTION is on, this key is to turn on or off SUCTION relay.
15	F	Not used (for extension)	
16	HEAT	Heating output (MAIN) display LED	
17	SUB	Heating output (SUB) display LED	
18	COOL	Cooling output display LED	
19	PUMP_D	Display pump running LED	
20	PUMP_R	Display pump inverse running LED	
21	WATER	Display water filling LED	
22	ALARM	Give the alarm LED	Refer to table 4-2 for errors type.

Table:4-2: Error Type

Error display	Reasons	Alarm	Temp.control
Board error	Controller error	Activated	Stop
Calib error		Activated	Stop
ADC error		Activated	Stop
RJC error		Activated	Stop
Eeprom error		Activated	Maintain its status
Phase error	Phase disconnect or phase reverse	Activated	Stop
Over temp. EGO	Contact input for ego temp. check	Activated	Stop
Over pump	Contact input for pumper overload check	Activated	Stop
Low press	Contact input for low pressure check	Activated	Stop
High press	Contact input for high pressure check	Activated	Stop
L. level water	Contact input for low water level check	Activated	Stop
Appear "-----" on temperature display	Sensor abnormality	Activated	Stop
Dve1 alarm	Deviation between control temp. and entered temp.	Activated	Maintain its status
Dev2 alarm	Deviation between control temp. and retrieved temp.	Activated	Maintain its status
Turb. Alarm	Control temp. is suddenly dropped	Activated	Maintain its status
Heater alarm	Control temp. does not rise	Activated	Maintain its status

Notes: When alarm sounds, controller will automatically start the protective function and stop the machine. Press "ON" to restart the machine after the troubleshooting.

## 4.2 Structure of the Unit



Picture 4-2: Menu Outline


### 4.3 Machine Startup

- 1) Connect pipeline from STM water in/outlet to the mold. (Refer to chapter 3.2 for pipeline connection)
- 2) Connect cooling water port and water backup port. (Refer to chapter 3.2 for pipeline connection)
- 3) Open all ball valves of the pipeline
- 4) Turn on main power switch.




Picture 4-3: Main Power Switch

- 5) Press ON/OFF POWER key to enter menu screen.



Picture 4-4: Initial Menu

- 6) Press MENU key to enter menu selection, press ◀/▶ keys to select control setting, press SET key to enter setting menu, see picture below. Parameter setting is based on AT auto-tuning. Never change it privately.




Picture 4-5: Control Setting

7) Press MENU key to return to menu screen, press ◀/▶ key to select alarm setting then press SET to enter setting menu, see picture below. Here is parameter setting:

- PHASE——used
- DEV1 ALARM——0 (without temp. sensor)  
5 (with temp. sensor, the value can be increased properly when alarm sounds frequently)
- DEV2 ALARM——0——0 (without temp. sensor)  
10 (with temp. sensor, the value can be increased properly when alarm sounds frequently)


- TURB ALARM—control temp.-10
- HEATER ALARM—based on auctual set value. If factory default value is 0, the heater alarm is not available.  
If there's 7.5°C difference compared with set temp. it will alarm.



Picture 4-6: Alarm Setting

8) Press MENU key to return to menu screen, then press ◀/▶ key to select output setting and press SET key to enter setting screen, see picture below. Here is parameter setting:


- OUTPUT MODE— heating or cooling control
- SUB HEATING— 0 (only 1 group of heater)
- 5 (two or more groups of heaters)
- COOLING TEMP— 35 (When forced cooling starts, control temp. is lower than the set value, the forced cooling will stop automatically).



Picture 4-7: Output Setting


9) Press MENU key to return to menu screen, then press ◀/▶ keys to select temp.setting, press SET key to enter setting screen, see picture below.

- H. LIMIT TEMP.— based on actual operation.
- L. LIMIT TEMP.— based on actual operation
- TEMP. UNIT— °C (Celsius and Fahrenheit)
- DEGREE— 0.1
- CTR TEMP BIAS— based on actual operation
- RET TEMP BIAS— based on actual operation
- ENT TEMP BIAS— based on actual operation




Picture 4-8: Temperature Setting

- 10) Press MENU key to return to menu screen, press ◀/▶ key to select time setting, press SET key to enter setting screen, see picture below. Time has been set before delivery; customers can set appointment time based on actual needs.




Picture 4-9: Time Setting

- 11) Press MENU key to return to menu screen, press ◀/▶ key to select communication setting, press SET key to enter setting screen, see picture below. If communication function is selected as an option, customers should set communication parameters based on actual needs.



Picture 4-10: Communication Setting


- 12) Press MENU key to return to menu screen, press ◀/▶ key to select device setting, press SET key to enter setting screen, see picture below. Before delivery, parameters have been set and customers can modify them based on actual needs.



Picture 4-11: Equipment Setting

- 13) Set mold temperature (if temp. has been set, this step can be ignored). Press SV key and control target value column will be flashing, press ◀/▶ key to move cursor then press ▲/▼ key to change values. Finally press SET key to confirm them. Maximum setting temperature of STM is 200°C.
- 14) After setting the target value, press RUN/RESET key to begin temperature

control, Auto-tuning is needed if deviation of control is a little bit large. Press AT key and LED light begins flashing to start Auto-tuning. When flashing ends, Auto-tuning finishes and parameters will be automatically saved. During Auto-tuning, pressing AT key will exit Auto-tuning process; controller will conduct temperature control based on parameters set before Auto-tuning.



Picture 4-12: Operation Screen

#### 4.4 Stop the Machine

- 1) Press COOL key to shut down heating output and cooling will be on 100%.
- 2) Wait until temp. drops below 50°C, press COOL key to shut down forced cooling, then press RUN/RESET key to stop operation.
- 3) tch off the main power.



Attention!

When main switch is turned on, be careful of electrical shock.



Attention!

Pump motor rotating direction should be the same with the indicator.



Attention!


In order to prolong machine lifespan, please do follow the above steps to turn on and off the machine.

## 5. Trouble-shooting

Failures	Possible reasons	Solutions
LCD displays nothing after switch on power and press ON/OFF key.	Did not connect through power supply. Main switch broken. Power supply wires problems. Control circuit fuse melt. Transformer broken.	Connect through power supply. Replace main switch. Check electrical wires. Fix the fuse. Replace the transformer.
Phase alarm.	Power supply low voltage. Phase shortage. Phase reversal. PCB problems.	Check power supply. Check power supply. Exchange two of the wires of power supply. Replace the PCB.
Pump overload.	Abnormal fluctuations of power supply. Pump blocked. Pump motor problems. Overload relay (F1) setting value error.	Check power supply. Check the pump. Check pump motor. Set the current of overload relay to 1.1 times of motor rated current. Please refer to Mian Components for detailed description of overload relay. Reset overload relay: Wait for one minute, then press the blue button to reset.
EGO overheat.	EGO temperature setting mistakes. EGO poor temperature detecting. Heater contactor problems.	Correctly set EGO temperature. (EGO temperature setting value= temperature setting value+10℃) Replace EGO. Replace the contactor.
Low liquid level.	Oil shortage.	Fill high temp. oil.
Temp. window displays “_ _ _ _”	Abnormal sensor.	Check and repair sensor.
Once running, pump output indicator works, but pump cannot start. After a while pump still fails to run.	PCB output relay problems. Electrical circuit problems. Pump contactor problem.	Check or replace the PCB. Check electrical circuit. Replace the contactor.
Difference between setting temp. and actual temp. is too big.	Too short time after machine startup. Temperature parameter setting error. Cooling solenoid valve problems.	Wait for a while. Check temperature parameters. Please refer to the standard manual of setting parameters. Replace solenoid valve.
Temperature can't rise up.	Heater contactor problems. Heater pipe problems. Thermocouple problems. PCB output point problems.	Replace the contactor. Replace pipe heater. Replace thermocouple. Check/ repair PCB.
Circuit breaker trips off when turning on main power switch.	Short circuit of main circuit. Transformer short circuit or connected with earth wire.	Check electrical wire. Replace circuit breaker.

	Problems of circuit breaker.	
Circuit breaker trips off when pump running for a while.	Pump motor coil short circuit. Problems of circuit breaker.	Check pump motor. Replace circuit breaker.
Circuit breaker trips off after heater output for a while.	Heater pipe short circuit or shell contact. Problems of circuit breaker.	Replace heater pipe. Replace circuit breaker.

## 6. Maintenance and Repair



1. Clean solenoid valve  
Period: trimonthly
2. Clean cooler  
Period: half yearly
3. Clean Y-type filter  
Period: half yearly
4. Clean heater pipe  
Period: half yearly
5. Clean liquid level switch  
Period: trimonthly

Use time of high temperature kerosene

≤ 120°C	Replacement period: yearly
≥ 120°C ~ ≤ 160°C	Replacement period: half yearly
> 160°C	Replacement period: trimonthly

Pay attention to the following rules during maintenance:

- 1) Need at least two persons present when checking the machine. Let the machine cool down, turn off power supply, drain out the oil and water. Make sure checking and maintenance space then start operation.
- 2) It's dangerous that machine works in high temperature. Stop the machine, wait it to cool down. Put on protective gloves before servicing or maintenance.
- 3) In order to prolong the life of the machine and to prevent accidents, check the machine at a fixed frequency.
- 4) ing operation, the oil is heated up to a high temperature, wait it to fall below 5°C then to perform repairing or maintenance.  
(Please note that it is dangerous to check or tear down the machine during operation.)

## 6.1 Y Type Strainer Cleaning

Clean soft water should be used as cooling water. Filter screen is used in the strainer to stop impurities and pollutants entering into water pipe. Impurities or pollutants may cause errors and bad temperature control. It needs to clean the Y type strainer periodically.

Cleaning steps: turn off power and cooling water supply. Open the top cover of filter screen to clean the filter.



Picture 6-1: Y Type Strainer

## 6.2 Solenoid Valve

Replacement steps:

- 1) Open machine top cover.
- 2) Open right side cover.
- 3) Take out the solenoid valve for replacement.
- 4) Install the covers in a reverse order.



Solenoid valve

Picture 6-2: Solenoid Valve

## 6.3 Heater Pipe Cleaning

After long use of the machine and with high temperature, there will be clingage and limscale accumulated on heater pipe which lower the heating efficiency. At this time, it needs to clean the clingage and limscale accumulated on heater pipe.

- 1) Open the heater cover (Press the black switch downward, then open the heater cover. As picture)



Picture 6-3: Heater Pipe 1

- 2) Take out the heater pipe (as picture, loose the screws, take out the heater pipe).



Picture 6-4: Heater Pipe 2

- 3) Heater pipe cleaning method: immerse the heater pipe into the thinner till all of the clingage fall off. Wet a cloth with some nature water, wipe the heater pipe cleanly and wait for the air drying.
- 4) After heater pipe cleaning up according to reverse orders to put them back to the machine.

## 6.4 Printed Circuit Board

MAIN terminal board drawing (refer to next page for terminal position and number).

① SENSOR TERMINAL1 (sensor terminal)

2, 3 : control temp. sensor terminal

5, 6 : return water temp. sensor terminal

8, 9 : water outlet temp. sensor terminal

11, 12 : 1~5V input terminal

② DI TERMINAL (contactor input terminal)

13, 14 : pump overload contactor input terminal

15, 16 : EGO overheat contactor input terminal

17, 18 : underpressure contactor input terminal

19, 20 : overpressure contactor input terminal

21, 22 : lower water limit contactor input terminal

23, 24 : upper water limit contactor input terminal

③ OUTPUT TERMINAL (output terminal for controlling)

1, 2 : heating control output MAIN (RELAY output)

3, 4 : heating control output SUB (RELAY output)

5, 6 : Cooling control output (RELAY output)

④ DO TERMINAL (relay contactor output terminal)

1, 2 : pump running contactor output terminal

3, 4 : pump inverse running contactor output terminal

5, 6 : backup water contactor output terminal

7, 8 : SUCTION 用触点输出端子

7, 8 : SUCTION contactor output terminal

9, 10 : alarm contactor output terminal

11, 12 : breaker contactor output terminal

13, 14 : reserve

⑤ PHASE CHECK TERMINAL (phase detect terminal)

1 : R phase connect terminal

2 : S phase connect terminal

3 : T phase connect terminal


⑥ DISPLAY CN (connect terminal for display)

Connect stub cable with STM100.

⑦ POWER TERMINAL (power supply terminal)

1 : FG terminal

2, 3 : power supply terminal (100~240VAC)



## 6.5 Display Terminal Connecting Diagram

① DI TERMINAL (contactor input terminal)

1, 2: RUN/STOP contactor input terminal

② COMM TERMINAL (comm terminal)

1, 2, 3, 4: rs485 comm terminal


5: Earth terminal

③ MAIN CN (MAIN earth terminal)

Connet to the electric cables which also connected with stm100

④ TEST PIN

Test pin No connection



## 6.6 Maintenance Schedule

### 6.6.1 About the Machine

Model \_\_\_\_\_ SN \_\_\_\_\_ Manufacture date \_\_\_\_\_

Voltage \_\_\_\_\_  $\Phi$  \_\_\_\_\_ V Frequency \_\_\_\_\_ Hz Power \_\_\_\_\_ kW

### 6.6.2 Installation & Inspection

Check the installation space is enough as required.

Check the pipes are correctly connected.

#### Electrical installation

Voltage: \_\_\_\_\_ V \_\_\_\_\_ Hz \_\_\_\_\_

Fuse melting current: 1 Phase \_\_\_\_\_ A 3 Phase \_\_\_\_\_ A

Check phase sequence of power supply.

### 6.6.3 Daily Checking

Check machine startup function.

Check all the electrical wires.

### 6.6.4 Weekly Checking

Check loose electrical connections.

Check and clean Y type filter <sup>(1)</sup>

Check solenoid valve.

Check motor overload and phase reversal alarm function.

Check whether pipeline joints are under looseness.

Check the sensitivity of EGO.

### 6.6.5 Trimonthly Checking

Check level switch.

Check the contactor <sup>(2)</sup>

Replace the hot kerosene with a using temperature above 160 degree <sup>(3)</sup>

### 6.6.6 Half-yearly Checking

Check damaged pipes.

Clean process heater/cooler.

- Check indicator and buzzer.
- Replace the hot kerosene with a using temperature above 120~160 degree <sup>(4)</sup>

### 6.6.7 Yearly Checking

- Replace the hot kerosene with a using temperature above 120 degree <sup>(5)</sup>

### 6.6.8 3 year Checking

- PCB board replacement
- No fuse switch replacement

Note: (1) Y-type strainer has the function of filling water cooling protection effect, be sure the waterway are clear to avoid cooling failure.

(2) Manufacturer laboratory data for AC contactor is two million times in life. we suggest service life for one million four hundred thousand times, if it works eight hours per day, recommended replacing frequency is one and half a year, if it works day and night, replacement is suggested to be done every six months.

(3) Hot kerosene coke will influence the detection accuracy of internal temperature probe and the efficiency of heat elements, three months replacing frequency is suggested.

(4) Hot kerosene coke will influence the detection accuracy of internal temperature probe and the efficiency of heat elements, six months replacing frequency is suggested.

(5) Hot kerosene coke will influence the detection accuracy of internal temperature probe and the efficiency of heat elements, suggested replacing frequency is one year.